## **VESDA VLF** VLF-250



The VESDA VLF-250 detector is a very early warning smoke detector designed to protect small, business-critical environments of less than  $250 \text{ m}^2$  (2,690 sq. ft.).

The detector works by continually drawing air into sampling holes in a pipe network. The air is filtered and passed into a detection chamber where light scattering technology detects the presence of very small amounts of smoke. Detector status information is communicated on the detector display and via relays or optional interface cards.

### **Out-of-the-Box Operation**

The VLF can be installed and commissioned out-of-the-box without the need for a special interface or software programming tools.

In operation, the unique Smoke Dial<sup>TM</sup> display provides the user with an instant understanding of a smoke event, even from a distance. Should a fault occur, the user simply opens the field service door and activates the Instant Fault Finder feature to determine the specific fault condition. This information can then be passed onto their fire service company, ensuring that service technicians arrive onsite fully prepared.

#### **Ultrasonic Flow Sensing**

The patent-pending Ultrasonic Flow Sensing used in the VLF provides a direct reading of the sampling pipe flow rate. The system is immune to air temperature and pressure changes and is unaffected by contamination. The VLF is the first air sampling smoke detector to use ultrasonic flow sensing.

### **Features**

- Out-of-the-Box Installation and Commissioning
- Ultrasonic Airflow Sensing
- Laser-Based Absolute Smoke Detection
- Pre-engineered pipe network designs
- Programmable Alarm Thresholds
- Clean air barrier optics protection
- Instant Recognition Display
- Instant Fault Finder™
- AutoLearn™ Smoke
- AutoLearn™ Flow
- Field Service Access Door
- Multiple Event Logging in separate logs
- Event log up to 18000 events
- Offline/online configuration capability
- Up to 250 m<sup>2</sup> (2,690 sq. ft.) coverage\*

### Listings / Approvals

- UL
- ULC
- CCC
- FM Class | Div ||
- ActiveFire (ISO/AS 7240-20)
- CE
- UKCA
- LPCB
- VdS
- VNIIPO
- NF
- EN 54-20
  - Class A (12 holes / 0.12% obs/m)
  - Class B (12 holes / 0.35% obs/m)
  - Class C (12 holes / 0.80% obs/m)

Classification of any configuration is determined using ASPIRE.

Regional approvals listings and regulatory compliance vary between product models. Refer to www.xtralis.com for the latest product approvals matrix.



# **VESDA VLF** TECHNICAL SPECIFICATIONS



#### **Specifications**

Input Power	Voltage: 24V DC Nominal (18-30 V DC) Current @ 24 VDC: 220 mA nominal, 295 mA in alarm		
Dimensions (W x H x D)	256 mm x 183 mm x 92 mm (101/16 in x 71/5 in x 32/3 in)		
Weight	Approx. 2 kg (4.4 lbs)		
IP Rating	IP30		
Mounting	Upright, inverted or horizontal		
Operating Conditions*	Ambient: 0°C to 39°C (32°F to 103°F)* Tested to (EN54-20): -10°C to 55°C (14°F to 131°F) Sampled Air**: -20°C to 60°C (-4°F to 140°F) Humidity: 5% to 95% RH, non-condensing		
Sampling Network	<ul> <li>Maximum pipe lengths: 1 x 25 m (80 ft) (Max. 12 holes) 2 x 15 m (50 ft) per branch (Max. 6 holes per branch)</li> <li>Sampling Hole Options: Pre-Engineered Option or Maximum Pipe length in accordance with Pipe Modelling Design Tool (ASPIRE™)</li> </ul>		
Air Inlet Pipe	Accepts both metric and American standard pipe sizes Metric: 25 mm (1.05 in.) American Pipe: IPS 21 mm (¾ in.)		
Area Coverage	Coverage Up to 250 m <sup>2</sup> (2,690 sq. ft.) depending on local codes and standards		
Relay Outputs	3 changeover relays (Fire 1, Action, Fault), Contacts rated 2A @ 30 VDC (max). NO/NC Contacts		
Cable Access	3 x 25 mm (1.05 in.) cable entries (1 rear entry, 2 top entry)		
Cable Termination	Screw Terminals 0.2-2.5 mm² (30-12 AWG)		
Interfaces	Shown in Terminal Block Connections diagram, to right, plus an RS232 Programming Port. General Purpose Input (GPI) interface offers: Reset, Disable, Standby, Alarm set 1, Alarm set 2 and External Input functions.		
Alarm Threshold Setting Range	Alert, Action: 0.025 - 2.00% obs/m (0.008 - 0.625% obs/ft) Fire 1, Fire 2: 0.025 - 20.00% obs/m (0.008 - 6.25% obs/ft) Individual Alarm Delays: 0 – 60 seconds Two Alarm Threshold Settings: Either time or GPI based		
Display	<ul> <li>4 Alarm State Indicators</li> <li>Smoke Level Indicator</li> <li>Reset, Disable and Test Control</li> <li>Fault and Disabled Indicators</li> <li>Instant Fault Finder</li> <li>Smoke and Flow AutoLearn Controlss</li> </ul>		
Event Log	Up to 18000 events, time and date stamped in separate, non- volatile, logs for: Smoke Level, Flow Level, Detector Status and Faults		
AutoLearn Smoke & Flow	<ul> <li>Automatically set acceptable alarm thresholds for both smoke and flow levels</li> <li>Minimum 15 minutes, maximum 15 days (default 14 days)</li> <li>During AutoLearn thresholds are NOT changed from preset values</li> </ul>		
Warranty Period	2 years		

## **Ordering Information**

Ordering Code	Description	Ordering Code	Description		
VLF-250-00	VESDA VLF. European language set. English display labels	VIC-010	VESDAnet Interface Card		
VLF-250-01	VESDA VLF. European language set. International display labels	VIC-020	Multifunction Control Card (MCC)		
VLF-250-02	VESDA VLF. English + Asian language set. International display labels	VIC-030	Multifunction Control Card (MCC) with Monitored Powered Output (MPO)		
VLF-250-03	VESDA VLF. Scandinavian language set. International display labels	VSP-005	Filter Cartridge		
VLF-250-04	VESDA VLF. English + Russian language set. International display labels	VSP-722	Aspirator for VESDA VLF-250		
VLF-250-05	VESDA VLF. English + Eastern Euro language set. International display labels				

## 3.5" Display

The display provided to the user includes a Smoke  ${\rm Dial}^{\rm TM}$  and alarm and status indicators.



When the field service access door is open, the user has access to the RESET (),

DISABLE **○**, Fire Test **○**, AutoLearn → and Instant Fault Finder functions. When the Instant Fault Finder function is activated, the Smoke Dial<sup>™</sup> converts to a fault indicator, with the dial segment numbers corresponding to the faults listed below.

### Legend of Fault Indicators

1	Filter	6	External Device/PSU
2	Aspirator	7	Interface card
3	High flow	8	Field wiring
4	Low flow	9	AutoLearn Fail
5	N/A	10	Detector failure

## **Terminal Block Connections**

	Ø		1	GPI	
	õ	笥	2	GPI	
	Ō	日	3	Display TX	
	Ō	司	4	Display RX	
	Ō	司	5	Display Common Ground	
	$\otimes$	T	6	Display Power -	
	$\overline{\otimes}$	T	7	Display Power +	
	$\otimes$	$\square$	8	Power Return 0 VDC	From power supply unit
	01	9	Power In 24 VDC		
	$\otimes$	E	10	Power Return 0 VDC	To next detector (if more than 1 detector
	$\otimes$	F	11	Power Out 24 VDC	per Power Supply Unit)
	ŏ	윰	12	NC	
	ō	笥	13	Common	Fault relay
			14	NO	
	ø	司	15	NC	
	ø	Ħ	16	Common	Action relay
	$\overline{\otimes}$	$\square$	17	NO	
	$\otimes$	Ē	18	NC	
1		Ē	19	Common	Fire 1 relay
	$\otimes$	$\Xi$	20	NO	

## **Approvals Compliance**

Please refer to the Product Guide for details regarding compliant design, installation and commissioning.

\* Product UL listed for use from 0°C to 38°C (32°F to 100°F).

\*\* Sampled Air temperature shall reach Ambient Detector temperature upon entry into Detector. Refer to Xtralis Design Guides & Application Notes for sampled air pre-conditioning.

## www.xtralis.com

Doc. No. 07854\_19 Part No. AD20293-002 August 2021 All technical data is correct at the time of publication and is subject to changes without notice. All Intellectual Property including but not limited to trademarks, copyrights, patent are hereby acknowledged You agree not to copy, communicate to the public, adapt, distribute, transfer, sell, modify or publish any contents of this document without the express prior written consent of Xtralis. Installation information: In order to ensure full functionality, refer to the installation instructions as supplied. © Xtralis